

# Total Carnage

## Manual Amendment

### Page 1-12, DIP Switch Test

This amendment provides additional information to the DIP Switch Test procedure.

The number of keys required to enter the Pleasure Dome is DIP switch selectable. See DIP Switch 1 Setting Table below.

**NOTE:** Switch positions SW3 through SW8 of Dip Switch DS1 determine the coinage of the game. To change coinage, set the coinage switch SW2 to ON, then change the setting of switch positions SW3-SW8 to the desired setting shown in the DS1 Chart. The game must then go through a **FULL FACTORY RESTORE** (found in the Utilities Menu) to activate the change in coinage.

**DIP Switch 1 (DS1) Setting Table**

		SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
200 Keys		ON							
220 Keys		OFF							
<b>Coinage</b>	DIP Switch Setting CMOS Coinage		ON OFF						
<b>COUNTRY</b>	<b>COIN MODE</b>								
USA 1	L=1/25 R=1/25 1 Credit to start, 1 credit to continue			OFF	OFF	OFF	OFF	OFF	OFF
USA 2	L=1/25 R=1/25 2 Credits to start, 1 credit to continue			OFF	OFF	OFF	OFF	OFF	ON
USA 3	L, R=1/2X.25; 2/3X.25; 3/4X.25			OFF	OFF	OFF	OFF	ON	OFF
GERMANY 1	L=1/1DM, R=6/5DM, (3)=2/2DM			OFF	OFF	OFF	OFF	ON	ON
GERMANY 2	L=1/1DM, R=7/5DM, (3)=2/2DM			OFF	ON	OFF	ON	OFF	OFF
GERMANY 3	L=6/5DM, R=2/2DM, (3)=1/1DM			OFF	OFF	OFF	ON	OFF	ON
FRENCH 1	L=2/5F, R=5/10F			OFF	OFF	OFF	ON	ON	OFF
FRENCH 2	L=2/5F, R=4/10F			OFF	OFF	OFF	ON	ON	ON
FRENCH 3	L=1/3X1F, R=2/5F, (3)=5/10F			OFF	OFF	ON	OFF	OFF	OFF
SWISS 1	L=1/1F, R=6/5F			OFF	OFF	ON	OFF	OFF	ON
ITALY	L, R=1/500 LIRE			OFF	OFF	ON	OFF	ON	OFF
UK 1	L=1/20P, R=3/50P			OFF	OFF	ON	OFF	ON	ON
UK 2	L=2/20P, R=5/50P			OFF	OFF	ON	ON	OFF	OFF
UK ELEC.	L=4/L1.00, R=2/50P, (3)=1/30P, (4)=1/3X10P			OFF	OFF	ON	ON	OFF	ON
SPAIN 1	L=1/25 PESETA, R=5/100 PESETA			OFF	OFF	ON	ON	ON	OFF
AUSTRALIA 1	L=1/3X.20, R=2/1.00			OFF	OFF	ON	ON	ON	ON
JAPAN 1	L, R, (3)=1/100 YEN			OFF	ON	OFF	OFF	OFF	OFF
JAPAN 2	L, R, (3)=2/100 YEN			OFF	ON	OFF	OFF	OFF	ON
AUSTRIA 1	L=1/2X5 SCHILLING, R=3/2X10 SCHILLING			OFF	ON	OFF	OFF	ON	OFF
BELGIUM 1	L=7/50F, R=3/20F, (3)=1/2X5F			OFF	ON	OFF	OFF	ON	ON
BELGIUM 2	L=3/20F, R=3/20F			OFF	ON	OFF	ON	OFF	OFF
SWEDEN	L=1/3X1 KRONA, R=2/5 KRONA			OFF	ON	OFF	ON	OFF	ON
NEW ZEALAND	L, R=1/3X.20			OFF	ON	OFF	ON	ON	OFF
NETHERLANDS	L=1/1HFL, R=3/2.5HFL			OFF	ON	OFF	ON	ON	ON
FINLAND	L=1/2X1 MARKKA, 3/5X1 MARKKA			OFF	ON	ON	OFF	OFF	OFF
NORWAY	L=1/2X1 KRONE, R=3/5X1 KRONE			OFF	ON	ON	OFF	OFF	ON
DENMARK	L=1/2X1 KRONE, R=3/5X1 KRONE, 7/2X5 KRONE			OFF	ON	ON	OFF	ON	OFF
				ON	ON	ON	ON	ON	ON

**DIP Switch 2 (DS2) Setting Table**

	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
<b>Test Switch</b>								
Game Mode								OFF*
Test Mode								ON

\* Indicates Factory Setting